ASSEMBLY INSTRUCTIONS

WORK BENCH STRINGERS

For Fixed & Adjustable Height Bench Legs

Model


ST-48

ST-60


ST-72

Important Note:

This stringer is used for both Adjustable Height and Fixed Height Bench Legs. For proper assembly the correct instructions (A or B) must be followed.




A. Adjustable Legs



Use the outside and middle holes on stringer, and bench leg when assembling benches using Adjustable Height Legs #ABL30, #ABL36.

B. Fixed Height Legs



Use the outside and inside hole when assembling benches using Fixed Height Legs #5707, #5708, #5709, #5710.



edral

4400 South Packers Ave. • Chicago, Illinois 60609

MANUFACTURERS OF QUALITY STEEL EQUIPMENT FOR IMPUSTRY, OFFICE & INSTITUTIONS